

# PowerTouch 914

Manual NST10393-1

Rev 0 03.04.02

Rev A 09.26.02

Rev B 04.14.03

Rev C 09.11.03

❖ By TouchTronics, Inc.

**Economical  
and  
Versatile**



914 PowerTouch Remote Control Receiver  
With Two (4 button) Key Chain Transmitters



Also showing optional:  
Two (two button) Key Chain Transmitters  
And Oval Transmitter

**Please read entire instruction manual *prior* to starting the  
PowerTouch Remote Control System Installation.**

## Special Features and Applications

- ❖ **Flexibility**  
Installer can select polarity of voltage outputs on all channels.
- ❖ **Power**  
All four outputs are 5 amp, switched relays.
- ❖ **Compact**  
Receiver is small and easy to install.
- ❖ **Optional Transmitters**  
Large, oval transmitters with large buttons can be ordered.
- ❖ **Program Options**
  - ❖ Two channels can be programmed as latching, On - Off
  - ❖ Channel 2 can be programmed with a 2-second courtesy light delay
- ❖ **Standard 4 Channels**  
Two and four channel transmitters are interchangeable.
- ❖ **Range**  
Typical antenna range is 60-feet.

**Contents**

Special Features and Applications	Page 1
Contents, Specifications, Installation Tools, Technical Support	Page 2
Component Parts List	Page 3
Operation: Remote Control	Page 3
Installation: Planning	Page 4
Installation: Receiver	Page 4
Installation: Electrical Connections	Page 5
Installation: Application Schematics	Page 6
Installation: Motors Using Relays, Safety Disable Switch	Page 7
Trouble Shooting Guide	Page 8, 9, 10
Limited One (1) Year Warranty	Page 11
Blank Page (Installation Notes or Diagrams)	Page 12

**Specifications**

914 Receiver:	FCC Approved
RF System	19,000 Digital Codes
Voltage	12 Volt DC (available in 24 Volt DC)
Output	5 Amp
Frequency	300 MHz
Range	60 Feet (typical - using standard 9" wire style, antenna)
Note:	Range may be extended with an externally mounted antenna
914 Transmitter:	FCC Approved
RF System	19,000 Digital Codes
Battery	12 Volt DC
Cycles	7,300 One Second Pulses
Frequency	300 MHz
Note:	Key chain style transmitters are water resistant, NOT water proof Oval style transmitters are water and dust resistant
Physical:	
Receiver:	4.5" x 2.5" x 1" (width, height, depth)
Transmitter:	1" x 2" (width, length) key chain style 2" x 4 ½" (width, length) oval(hand held) style

**Installation Tools**

Voltmeter, analog or digital  
Phillips Screw Driver  
Adjustable Wrench  
Screw Driver  
Wire Cutter  
Wire Stripper  
To Clean Grounding Pad: Scraper, Sand Paper, Alcohol Based Cleaner

**Technical Support**

Visit the factory website to download a copy of these instructions, e-mail technical questions and see other TouchTronics, Inc. products.

**Phone / Fax Numbers**

Indiana Local 1-574-294-2570  
Toll Free 1-800-294-2570  
Fax 1-574-293-1611





**Web Site**

[www.touchtronics.com](http://www.touchtronics.com)

**E-Mail**

[Touchtronics@touchtronics.com](mailto:Touchtronics@touchtronics.com) or  
[techsupport@touchtronics.com](mailto:techsupport@touchtronics.com) or  
'Contact Request' link on the web page

## Component Parts List

- |          |       |         |  |   |
|----------|-------|---------|--|---|
| 1)       | 1 pc  | 914r    | RF Receiver, 4 Channel w/9" antenna wire     |   |
| 2)       | 1 set | 914h    | Harness - 10 wire, 9"                        |   |
| 3)       | 2 pcs | 914T4   | Transmitter, 4 button key chain style        |   |
| Optional |       | 914T2   | Transmitter, 2 button key chain style        |   |
| Optional |       | 914T4XS | Transmitter, 4 button oval (hand held) style |  |

## Operation: Remote Control

**Transmitters:**

- |    |                          |   |
|----|--------------------------|---|
| 1) | Press and release button | Signal is sent to receiver - 1 second pulse   |
|    | Or                       |   |
| 2) | Press and hold button    | Signal is sent to receiver as long as button is held. Signal will stop when button is released.             |
| 3) | Red Status LED           | A) LED On red indicates signal is being sent<br>B) LED On bright and solid indicates battery voltage is ok. |

**Transmitter Operation**

**Receiver Operation**

2 Button Transmitter	4 Button Transmitter	Channel	Function	Output	Power Output <small>All outputs must be same polarity</small>	Signal Type
1	1	1	Motor or Lamp	5 Amps Max	+12v or Ground(-)	Momentary
1 & 2 <small>Pressed at the same time</small>	2	2	Motor or Lamp	5 Amps Max	+12v or Ground(-)	Momentary 22 sec delay (ch 4) <small>*See example below</small>
2	3	3	Motor or Lamp	5 Amps Max	+12v or Ground (-)	Momentary Or Latching
N/a	4	4	Motor or Lamp	5 Amps Max	+12v or Ground (-)	Momentary Or Latching

\*Example - Courtesy light turns on for 22 seconds when button 2 is pressed, and the channel 4 output is connected to the courtesy lights.

# Installation: Planning

## 1) Receiver Output Voltages

- A) The receiver has four output voltage (channels) which will operate four separate circuits. The output voltage is 12 volts direct current (vdc). The maximum drive current for each of the four output channels is **5 Amps (maximum)**. The four outputs can turn On (drive) bulbs, relay coils or small motors.
- B) Check the power requirement for the bulb or motor before connecting to the receiver.  
Maximum 5 amps @ 12vdc or 60 watts @ 12vdc

## 2) Determine where the receiver and antenna will be located.

Typically the RF receiver is located under the dash or behind a wall panel in the back. If the receiver is to be mounted outside the cab area then you must protect the receiver. The receiver is NOT waterproof or moisture resistant\*.

**DO NOT** mount the receiver and antenna:

- A) Within 6 feet of a motor
- B) Near large bundles of wires
- C) Near other antennas or RF devices
- D) The antenna should not be touching any metal as this grounds the RF (radio frequency) signal

Range of your Remote Control is affected by the installation location of the receiver antenna

\*TouchTronics offers weather resistant housings for many different types of applications. Call the factory @ 1-800-294-2570 for information on your particular application needs.

# Installation: Receiver

### **WARNING!**

Use **ONLY** a volt meter to check voltage during installation and testing.


*\*Using a test light WILL damage the outputs!*



Notes:

- 1) Channels 1 and 2 are momentary outputs as long as the button is pressed.
- 2) Channels 3 and 4 are factory set as momentary outputs as long as the button is pressed. These outputs can be programmed as latching (push on - push off). Call the factory for program information at 1-800-294-2570

**\*Maximum output current 5 Amps. Over current will damage outputs.**



Scrape paint and clean area before installing ground screw.

**A loose chassis ground connection WILL cause intermittent operation!**

# Installation: Electrical Connections

## 1) Install Power

Connect the Red wire to a constant +12v battery power source. Note: For best performance, run a clean +12v (15A) directly from the battery or a fuse that is NOT supplying any power to motors, lights or any other type of high current device.

See Diagram  
on Page 4

	Input	Wire Color	Max Input	Pin Position
Logic Power	+	Red	1 Amp	01
Relay Power	+	Purple	10 Amp	11
Ground	-	Black	1 Amp	03
Orange - Pin 4 - Not Used				

## 2) Install Ground

Connect the Black wire to chassis ground

- A) Scrape all paint and grease away from the body frame.  
**A loose chassis ground connection WILL cause intermittent operation of receiver.**
- B) Clean the area using an alcohol based cleaner to remove paint chips and grease.
- C) Crimp a #10, 3/16" ring terminal onto the black ground wire.
- D) Insert the ring terminal and a #10, 3/16" star washer over a 10x3/4" hex head, self-tapping ground screw.
- E) Tighten ground screw securely into clean frame area.

## 3) Install Outputs - Maximum output is 5 Amps per channel



- A) Connect *only One* Channel output wire at a time to a relay or function which uses 5 Amps
- B) Solder connections and protect with shrink tube or use an 18g insulated butt terminal.

## 4) Wiring Inspection

- A) Check all wiring connections visually
- B) Check the polarity of all wires
- C) Tape off or remove all unused wires.

Channel	Output	Wire Color	Max Output	Pin Position
Channel 1	RR@G	Green / Black	5 Amp	09
	(+) positive	Green / Red	5 Amp	07
Channel 2	RR@G	Yellow / Black	5 Amp	08
	(+) Positive	Yellow / Red	5 Amp	06
Channel 3	(+) Positive	Tan	5 Amp	10
Channel 4	(+) Positive	White / Tan	5 Amp	12

See Diagram on Page 4 - 'Installation: Receiver'







# Installation: Suggested Application Schematics

The following schematics are for reference only. The installer must verify that the circuit is properly wired with the correct gauge of wire, and properly fused with the correct fuse size and type for the circuit.

Vehicle window switches and door lock switches can be designed as a positive pulse, a negative pulse or a reversal rest @ ground circuit.

To determine which type is used in your vehicle, take a voltmeter and probe one of the output wires at the switch. Check the polarity with the switch pressed and without the switch pressed. Compare results with the chart below.

Window or Door Lock Switch	Switch NOT Pressed	Switch Pressed	Typical # of Wires
Positive Pulse	No Voltage / Floats	+12 Volts	3 Wires
Negative Pulse	No Voltage / Floats	Ground	3 Wires
Reversal Rest@Ground	Ground	+12 Volts	5 Wires










**\*\*Please Note:**

Due to continually changing wire colors through-out the automotive industry, TouchTronics can NOT provide accurate wire color information on a consistent basis. Therefore, if the wire colors needed for installation are not known, please contact a local dealer and they should be able to provide any necessary information.

# Installation: Motors Using Relays, Safety Disable Switch


**WARNING!** *If using any type of motor, such as a window motor, a ramp motor, a door motor, or a winch motor - add a Disable switch to prevent the door or window circuit from operating when vehicle is in motion.*

A disable switch should be installed in many applications to deny operation of the motor when a vehicle is in motion. However, due to changes in automotive electrical design and the addition of computer controlled circuits, it is no longer advisable or safe to tap into or cut wires to disable automotive factory circuits. To overcome this problem, you must install an electro-mechanical switch which will determine gear position, thus safely disabling the circuit while the vehicle is in motion. Below are three options for installing a Safety Disable Switch.




# Installation: Application Schematics


## Multiple Motors



## 10 Amp Motor Application For Reversal Rest @ Ground - Channels 1 and 2




## 20 / 30 Amp Motor Application for Reversal Rest @ Ground System - Channels 1 and 2



**\*Note: All wiring and components must be sized properly for this high current application.**

## Street Rod Application



**\*Note: All wiring and components must be sized properly for this high current application.**

**\*\*Safety relay circuit when using door open function**



## Trouble Shooting Guide - 914 Series Remote Control



**Use a digital or analog voltmeter to check power and voltage!  
Do NOT use a test light**

Symptom	Possible Cause	Corrective Action								
<p><b>1.0</b> No output from one or more channels on remote control receiver</p>	<p><b>1.1</b> No signal from transmitter</p> <p><b>1.2</b> One or all of the outputs have failed.</p> <p><b>1.3</b> Power wire not connected</p> <p><b>1.4</b> Receiver outputs ok, but relays or equipment does not operate.</p>	<p><b>1.1a</b> Verify that transmitter is sending a signal and that transmitter is coded correctly.</p> <p><b>1.1b</b> See symptom 3.00</p> <p><b>1.2a</b> Press each transmitter button in sequence. While pressing button, <i>use only a voltmeter probe</i> to check each corresponding output</p> <table style="margin-left: 40px; border: none;"> <tr> <td style="padding-right: 20px;">Green / Black</td> <td>Button '1'</td> </tr> <tr> <td>Yellow / Black</td> <td>Button '2'</td> </tr> <tr> <td>Tan</td> <td>Button '3'</td> </tr> <tr> <td>White / Tan</td> <td>Button '4'</td> </tr> </table> <p><b>1.2b</b> If checking voltage, a positive signal is present when button is pressed and float when not pressed if input to purple wire is +12v.</p> <p><b>1.2c</b> If outputs read nothing when pressed or not pressed and you do not hear the relay clicking, then the power supply is damaged. Send back to factory for repair or replacement.</p> <p><b>1.2d</b> <i>Any of the above problems can be caused by a defective unit or damage by the customer from over-voltage, over-current or testing the inputs and outputs using a test light instead of a voltmeter.</i></p> <p><b>1.3</b> Check voltage on purple wire - if +12v not present, check wire harness for problems.</p> <p><b>1.4</b> Check wire and equipment for problem</p>	Green / Black	Button '1'	Yellow / Black	Button '2'	Tan	Button '3'	White / Tan	Button '4'
Green / Black	Button '1'									
Yellow / Black	Button '2'									
Tan	Button '3'									
White / Tan	Button '4'									
Symptom	Possible Cause	Corrective Action								
<p><b>2.0</b> Signal transmitted and relay chatter in receiver, but no operation.</p>	<p><b>2.1</b> One or both of the outputs have failed</p> <p><b>2.2</b> Receiver has failed outputs</p>	<p><b>2.1a</b> Check wire harness for loose connections or damaged wires or terminals</p> <p><b>2.1b</b> Check equipment for problem in motors or relays</p> <p><b>2.2</b> Recheck section 1.0</p>								

## Trouble Shooting Guide - 914 Series Remote Control



**Use a digital or analog voltmeter to check power and voltage!  
Do NOT use a test light**

Symptom	Possible Cause	Corrective Action
<b>3.0</b> No power to remote control receiver	<b>3.1</b> Logic ground or power connection to receiver has failed  <b>3.2</b> Chassis ground connection has failed	<b>3.1a</b> Check ground (black wire) and power (red wire). Use a voltmeter probe when checking voltage. <b>3.1b</b> If either ground or power is not present, then locate failure in wire harness and repair.  <b>3.2a</b> Check chassis ground connection, it should be clean and tight, no paint on metal, an external tooth star washer should be present, no rust or dirt in connection. <b>3.2b</b> Chassis ground should be located on vehicle frame.
Symptom	Possible Cause	Corrective Action
<b>4.0</b> No signal (code) being transmitted	<b>4.1</b> Battery voltage low  <b>4.2</b> Transmitter is not sending a signal  <b>4.3</b> Transmitter code is incorrect  <b>4.4</b> Not all buttons send a signal when pressed.	<b>4.1</b> Check battery voltage. Replace battery if voltage is 8.5 volts or less. (Signal strength is dependent upon battery voltage.)  <b>4.2</b> Place probe from voltmeter on battery (+) and (-) leads. Press any button, voltage should change by 0.2 to 0.3 volts if a signal is transmitted. Check both buttons.  <b>4.3a</b> If transmitter is sending a signal and no signal is being received, re-code transmitter. <b>4.3b</b> Send back to factory for re-coding.  <b>4.4</b> If a signal is not transmitted on all buttons, send back to factory for repair or replacement.
Symptom	Possible Cause	Corrective Action
<b>5.0</b> Poor range 0' to 25' (pulsating 0' to 25')	<b>5.1</b> Antenna damaged or grounded	<b>5.1a</b> Check antenna placement, it should not be touching any metal or tinted glass. <b>5.1b</b> It should not be closer than 6' to any motors or relays. <b>5.1c</b> If it is coiled, then stretch it out and place near a window. <b>5.1d</b> If antenna is cut or damaged, send back to factory for repair. <b>5.1e</b> <i>NOTE: Antenna can NOT be shortened or altered in any way</i>

## Trouble Shooting Guide - 914 Series Remote Control

Symptom	Possible Cause	Corrective Action
<b>5.0</b> Poor range 0' to 25' (pulsating 0' to 25')	<b>5.2</b> Receiver installed in poor locations such as near door or lift motor	<b>5.2a</b> Disconnect door and / or ramp motor and recheck range. <b>5.2b</b> If range is ok, then 'electrical noise' from motors is causing interference with RF signal. <b>5.2c</b> Move receiver and antenna a minimum of 6 feet from the motors. <b>5.2d</b> If moving receiver 6 feet does not improve, an external antenna may be required to boost signal.
	<b>5.3</b> Receiver logic power input is exposed to radiated noise from wire harness or motors	<b>5.3a</b> Disconnect receiver logic power input from main wire harness <b>5.3b</b> Run new wire from vehicle battery to red wire.
	<b>5.4</b> Receiver logic ground is exposed to radiated noise from wire harness or motors	<b>5.4a</b> Disconnect receiver logic ground input from main wire harness <b>5.4b</b> Remove black wire on receiver from wire harness and install on the vehicle frame for a new chassis ground or vehicle battery. <b>5.4c</b> Remove any paint or residue from metal, use an external tooth star washer and tighten new chassis ground terminal securely to vehicle frame.
	<b>5.5</b> Transmitter 9-volt battery is low	<b>5.5</b> Replace battery if voltage is 7.5 volts or below
	<b>5.6</b> Out of 25 foot range	<b>5.6</b> Move closer to the vehicle
	<b>5.7</b> Interference	<b>5.7a</b> Electromagnetic interference (EMI) caused by any radio frequency (RF) nearby, motors, welding equipment, relays, etc. May be in close proximity to receiver / transmitter. <b>5.7b</b> Move closer to antenna or move vehicle out of range of EMI caused by radio frequency, welding equipment, as this is a temporary problem. <b>5.7c</b> If EMI is caused by relays, door motors or lift motors then the receiver must be moved or shielded or the EMI noise diverted to ground. Call the factory for details.
	<b>5.8</b> Component of receiver damaged or defective	<b>5.8</b> Send back to factory for repair or replacement.
	<b>5.9</b> Other equipment installed in vehicle causing voltage drop when initially turning on	<b>5.9</b> Remove all other equipment from logic ground and power.

## TouchTronics, Inc. Warranty Policies and Procedures

The following revised warranty procedures will be implemented and effective March 1, 2002.

- 1) All products will now be shipped with an individual bar code attached.
- 2) The bar code will include some or all of the following information.
  - A) Date of Manufacture
  - B) Serial Number
  - C) Private Code
  - D) Part Number
- 3) Warranty Cards are no longer required to be eligible to receive technical support and service.
- 4) Each individual product is warranted under the TouchTronics Limited Warranty program for 1 full year from date of purchase or a *maximum* of 2 years from the date of manufacture.
- 5) No product will be covered under the TouchTronics Limited Warranty program that has a manufacture date older than 2 years.
- 6) To receive technical support or warranty service, simply call our technical support center during regular business hours.
- 7) To enable our technical support staff to better serve you, please have the following information available when you call.

Date Of:	
Manufacture	
Purchase	
Installation	

Vehicle Information:	
Dealer Name	
Dealer Phone	
Make / Model	

Product Information:	
Part Number	
Serial Number	
Private Code	

**Please fill in all pertinent information at the time of purchase or installation**

### Limited One (1) Year Warranty

#### Section One

Seller will warrant any product originally manufactured or assembled and sold by seller for a period of *up to TWO YEARS* (24 months) from the original date of manufacture or **ONE YEAR** (12 months) from the original retail sale or O.E.M. in-service date.

#### Section Two

The following are in lieu of all warranties; expressed; implied; or statutory, including but not limited to, any implied warranty of merchantability of fitness for a particular purpose and of any other warranty obligation on the part of seller. Seller, except as otherwise hereinafter provided, warrants the goods against faulty workmanship or the use of defective materials for a period of *up to TWO YEARS* (24 months) from the original date of manufacture or **ONE YEAR** (12 months) from the original retail or O.E.M. in-service date.

Sellers sole and exclusive liability shall be (at sellers option) to repair; replace; or credit buyer for such goods which are returned by buyer during the applicable warranty period set forth above, provided that (I) seller is promptly notified in writing or phone upon discovery by buyer that such goods failed to conform and an explanation of any alleged deficiencies, (II) such goods are returned to seller, (III) sellers examination of such goods shall disclose that such alleged deficiencies actually exist and were not caused by accident, misuse, neglect, alteration, improper installation, unauthorized repair or improper testing. If seller elects to repair or replace such goods, seller shall have a reasonable time to make such repairs or replace such goods.

Sellers warranties as herein above set forth shall not be enlarged, diminished, or affected by, and no obligation or liability shall arise or grow out of, sellers rendering of technical advice or service.

Damage to products caused by the customer or during installation cannot be claimed under this warranty. All devices returned that are not covered under the sellers warranty policy, will be charged a minimum of \$25.00 for evaluation plus additional charges for components and labor to repair the device not to exceed the original selling price. Seller considers the following to be typical examples of customer or installation damage: burned or broken traces on the printed circuit board, burned or damaged components, dirt or water residue on the printed circuit board or inside the case, modifications by the customer, broken cases or housings and dead batteries.

#### Section Three

A return material authorization number (RMA) must be issued by seller before any product is returned for evaluation or repair. Warranty repairs must be completed at authorized repair facilities.

Warranty policy 1 rev a.doc  
01.01.03 rev a  
09.30.98 rev int  
Effective January 1, 2003