

TOUCHTRONICS, INC. ❖

57315 Nagy Drive
Elkhart, IN 46517

web site address: www.touchtronics.com
e-mail address: touchtronics@touchtronics.com

ph: 574-294-2570
fx: 574-293-1611

Coding 919 Series Transmitters

02/05/01

Document: D919-d1.doc

Revision A - 04.03.01

The receivers in the 919 series of remote controls are designed to learn any 919 series transmitter code. The following instructions will tell you how to place the receiver in the "Learn Mode". The receiver can learn up to four different transmitter codes.

Coding the Transmitter:

- 1) Turn transmitter power switch 'ON'. The power switch is located on the side of the transmitter.
- 2) **To prevent functions from operating during the coding process, disconnect the relay outputs by unplugging connectors 'J1' and 'J2'.**
- 3) Press and hold the #1 button on the transmitter *while you are doing step #4 (a or b)*.
- 4) To place the receiver into "learning mode"
 - a) Take the brown wire, located in connector J5 - position 5, (small 6-pin connector) and touch it three (3) times to a +12V source within a 5-second time period.
 - b) In some cases, a momentary toggle switch has been installed which provides this "learning mode" signal. Turn toggle switch 'ON' and 'OFF' three (3) times within a 5-second time period.
- 5) When the code is learned, the channel #1 relay will click 'ON'.
- 6) Test the newly coded transmitter by pressing all other buttons (1-9) one at a time. If the receiver has correctly learned the new code, the corresponding relay should click 'ON'.
- 7) If the new code has not been learned by the receiver, try the coding process a second time.

If there are any problems recoding the transmitter, please call the factory at 800-294-2570.